



ELECTRICIAN,

To Install:

Remove existing bell switch and mount the AutoBell module over the recess

Bring the bell pair through the back of the mobile base and connect to the strip connector (2 red wires) ---- Contacts are normally open mode

Power supply can come through the rear also if possible (adjacent lighting circuit OK, but should have an isolating switch)

Alternative – fit a flex and plug extension from side or underside of the enclosure (lug supplied)

The Omron programmer is pre-programmed

Any queries, please call Ian on 027 495 4033

Ian Burt
TimeLab

